



LAWN MOWER



Depending on the model purchased, packaging will contain different accessories and parts.
Refer to the package for more details.


KNOW YOUR PRODUCT

- 1 Start button
- 2 Blade activation lever
- 3 Upper handle
- 4 Knob
- 5 Lower handle
- 6 Rear discharge door
- 7 Quick-release lever
- 8 Battery door
- 9 Height adjustment lever
- 10 Grass catcher
- 11 Mulch plug




1 INSTALLATION

Install the lower handle



2

Install the upper handle



3



Europe
www.greenworkstools.eu




USA
www.greenworkstools.com




Canada
www.greenworkstools.ca

Rear bagging setup




4

Mulching setup



5


Set the blade height



6




Install/remove the battery



7

OPERATION


Start the product




8

MAINTENANCE

Mower blade replacement



9



10