



### Quick Start Guide

#### LED FLASHLIGHT



- |                 |                  |
|-----------------|------------------|
| 1. LED Bulb     | 3. Pivoting head |
| 2. Power button | 4. Hanging hook  |

Depending on the model purchased, packaging will contain different accessories and parts. Refer to the package for more details.

# greenworks®



Europe  
[www.greenworkstools.eu](http://www.greenworkstools.eu)



USA  
[www.greenworkstools.com](http://www.greenworkstools.com)




Canada  
[www.greenworkstools.ca](http://www.greenworkstools.ca)


Rev B1

## OPERATION

Adjust the angle




3



### Install the battery


4



To remove the battery, press and hold the battery release button then pull it out of the product.

5

### Start the product



### Select mode (cyclical)

6

|                                                                                          |         |
|------------------------------------------------------------------------------------------|---------|
|  X1 | ● Low   |
|  X2 | ○ High  |
|  X3 | ● ☀ SOS |
|  X4 | ● OFF   |