

ASSEMBLY INSTRUCTION


DE - MONTAGEANWEISUNG
FR - INSTRUCTIONS DE MONTAGE
DK - MONTAGEVEJLEDNING
CZ - NÁVOD K MONTÁŽI
ES - INSTRUCCIONES DE MONTAJE
FI - ASENNUSOHJE

HR - UPUTE ZA MONTAŽU
SE - MONTERINGSANVISNING
SI - NAVODILA ZA MONTAŽO
TR - MONTAJ TALIMATI
NO - MONTASJEANVISNING
IT - ISTRUZIONI DI MONTAGGIO

GR - ΟΔΗΓΙΑ ΣΥΝΑΡΜΟΛΟΓΗΣΗΣ
NL - MONTAGE INSTRUCTIE
PT - INSTRUÇÕES DE MONTAGEM
PL - INSTRUKCJA MONTAŻU
HU - SZERELÉSI UTASÍTÁS



20 min




0 cm
1
2
3
4
5
6
7
8
9
10
11
12
13
14



x 6

HW-ST-01-041
(7 x 55)




(A) x 1

SU-BE-LF-0252


(E) x 4

C-W-BE-SP-0004




(F) x 2

SU-BE-ST-0177



x 4

HW-ST-01-046
(7 x 90)




(B) x 1

SU-BE-LF-0253



x 4

HW-ST-02-054
(8 x 40)




(C) x 1

SU-BE-ST-0180




x 12

HW-ST-01-01
(4 x 30)





(D) x 1

SU-BE-BF-0139





x 2



HW-ST-18-001
(4 x 98)





1/5



2/5



3/5



4/5

