



















GFS00094C




ASSEMBLY INSTRUCTION

PARTS NO	QTY	DESCRIPTION				
A	4					
B	4					
C	4					
D	4					
E	4					
F	4					
G	1					
H	4					
I	1					
J	12+1		M6*12	N	8	
K	16+1		M6*32	O	2	
L	12+1		M6*58	P	1	
M	28+1					


STEP 1




STEP 2




STEP 3




STEP 4




STEP 5



STEP 6



STEP 7



STEP 8

